

IEEE 1149.1/JTAG TDRs which cross power domains require control cells and muxes

CJ Clark, Intellitech Corp.

For IEEE 1149.1/JTAG WG Review




Muxes in 1149.1 are not new.

IR and TDRs have been muxed within
the IC since the standard originated

Linking devices link via muxes

Recall that Board level scan-chains – loading bypass as an IR scan changes length by 31 bits for the subsequent DR scans
- tracking lengths of chains and muxing of TDRs has been with us for some time




Bits in a board level scan-chain - well known
linking device collapses or expands chain via a MUX

TI device has control bits at end after paths, other devices
have control for muxes prior to the path

TI Scan Path Linker




Other 'linking' devices




Why can't the Boundary Register be in the same power domain as the TAP?

The IC power today is segmented (cores and I/O)




Without segmentation, If one part of boundary register crosses an area where there is no power (due to defect, dc/dc off, etc) then the whole boundary register is un-scannable. This design is compliant as far as I know, but a single power defect corrupts the entire boundary register contents.




Is there any part of this design which is non-compliant?
- I don't think so, but a single fault from power or external power is 'off' will prevent scanning the b-s register.

The standard mandates and recommends b-s cells with a view that I/O IP must be delivered separately from the cells
- this limits the choices the industry has and the ease of design




challenges exist for having observe cells on a leg and keep it in the 'TAP' or 'boundary scan' power domain (distance, isolation, leakage etc)



Now add INIT_DATA input to the SERDES, for voltage, protocol, pre-emphasis, etc. How many power isolation cells and level shifter are needed by the designer?

Explosion in count of level shifters and power isolation cells as so many signals have to cross to the 'TAP' power domain



Boundary scan chain power domain


power isolation cells/level shift

I/O power domain

What about IP that has integrated b-s cells?

- require b-s cells on the n-bit parallel interface?
- 40 b-s cells?

How to use the 40bit PISO interface?



integrated B-s cell in IP
How to use and keep powered?


Boundary scan chain
power domain

I/O power domain

By allowing boundary and INIT_DATA in the IO power domain, the job is easier - Fewer Level shifters/isolation cells

Only one set of Clause 9 1149.1 signals for many I/O need to traverse the domain.
TCK
capture_<tdr>
update_<tdr>
shift_<tdr>
reset_<tdr>
SI/SO
for INIT_DATA and boundary
(or gated clock equivalent)
+ Mode/chmode

TAP domain




Many I/O to few power domain crossings is easier, routing easier area easier

I/O power domain

Segmentation offers several advantages.

- easier for IC designer to manage I/O in multiple power domains
(Our standard has to be practical for today's designs)



**Test engineer
can isolate the
fault to a
segment/area**


OK, the boundary register is shown around the edge, which is not typical of today's IC. (bear with me)

Segmentation offers new segmented EXTEST capabilities

- the ad-hoc use has been discussed in papers
- vendors don't need support it if you don't see the benefit

IC segments
in mission mode

Two IC segments
in test mode



But, the full boundary scan register has served us well for 20+ years

- yes it has. Now we have to be realistic about the problems associated with the b-s register (or init_data) in a single power domain

We're going to far, I don't want to modify my software

- Our standard isn't useful if the \$300Billion IC industry doesn't follow it or has non-compliant ICs. It would be disproportionate in terms of cost for semiconductor vendors to spend more money (design time and area) on EACH IC design to overcome the power domain problem because a small segment of tool vendors with more representation on the WG don't want to support parsing two special bits of each b-s segment. Both values must be a '1' to keep the mux 'ON' and the power 'on'. Simply scan those values in all the time as if they were internal cells in a BOUNDARY_REGISTER description.

What do we need to add to TDRs to support the TDR crossing a power domain?

Two TDR cells needed prior to crossing the power domain
 - cells are defined by REGISTER_FIELDS in BSDL

A 'power' cell as shown in figure 9-6 of draft.

The Power state (on/off) is captured at PI of the cell and the power state is turned on/off at PO.
 (Power observation is through level shifter)





Figure 9-6— A capture-update TDR cell with non-gated clock and optional reset

A control cell is a selfmon type cell, the output of the cell is captured (PI to PO in figure 9-6 of draft.)

The control cell (cmux) controls the mux to insert or remove a segment.




what happens when a TDR (boundary, init_data, etc) cross power domains?


A 2 bit power & control of mux could configure chain as needed.

1 bit for mux control (CMUX) , one bit for power domain override (POWER)


- observe if domain is 'functionally' on (may be necessary for some TDRs)
- Override domain power on/off for test purposes
- selfmon type cell allows observation of mux control (did it achieve 'on')



Or if WG prefers it could be done this way. Initial state (reset) is known To be 'off/collapsed'.



TDR segments within an IC




Rules: Mux and cells are always outside of Power Domain

Power mux cells control mux on 'other side' of domain prior to next Power Mux or TDO (No power_mux around another power mux)

2 bits, one cell controls mux and other is optional to override system which may have power domain off.

A capupd cell is one of the cells we have not allowed yet as a pre-defined Cell like NOPI or NOPO. CAPUPD captures from the update register. The mux Control is a critical signal that needs testability. One could argue that Power_sense Could be used instead of UPD as the capture value. One could also argue that The cells after the Path2 must be used for obtaining value from CAPUPD on mux control

TDR segments within an IC




But it's too simple, it's not showing the power controller, Isolation cells (ISO), Level Shifters (LS), and Retention Registers (RR).

That's right. 1149.1 would be mute on forcing the designer to design it a certain way. The only thing we are defining is that there is a power observe, a power override and a separate self-monitoring cell which controls the mux. The definition of the control cell for the mux is that it powers up in the 'off' state, the mux with the short path on.

BOUNDARY REGISTER TDR segments within an IC

- mode is gated with CMUX output



How can we describe this?

REGISTER_ASSEMBLY has been proposed and accepted
- Scan chain length deferred and calculated from R_A

attribute REGISTER_ASSEMBLY of chip_2011 : entity is

```
"INIT_DATA ( "&  
  -- TDI  
  "(USING SerdesO),( i1 IS init_data DEFAULT.ALLBITS (CHPMFG(Test)) ), "&  
  "(USING SerdesO),( i2 IS init_data DEFAULT.ALLBITS (CHPMFG(Test)) ), "&  
  "(USING SerdesH),( i3 IS init_data DEFAULT.ALLBITS (CHPMFG(Test)) ), "&  
  "(USING SerdesO),( i4 IS init_data DEFAULT.BSTERM (BSTERM(CPflt))  
DEFAULT.BSCM (BSCM(DC_CPL)) DEFAULT.BSSWING (BSSWING(1115mV)) ) "&  
  -- TDO  
  ")";
```

REGISTER_ASSEMBLY with i1, i2, i3 and i4 provide 4 x 6 bits or 24 bits of scan data.
(John Siebold example, recall SERDESH and SERDESO have a 6 bit tdr segment).

Recall that without i3 in the description the same process
Takes place of reading the instances and totaling up the
Lengths.

attribute REGISTER_ASSEMBLY of chip_2011 : entity is

```
"INIT_DATA ( "&  
  -- TDI  
  "(USING SerdesO),( i1 IS init_data DEFAULT.ALLBITS (CHPMFG(Test)) ), "&  
  "(USING SerdesO),( i2 IS init_data DEFAULT.ALLBITS (CHPMFG(Test)) ), "&  
    -- i3 is missing or commented out  
  "(USING SerdesO),( i4 IS init_data DEFAULT.BSTERM (BSTERM(CPflt))  
  DEFAULT.BSCM (BSCM(DC_CPL)) DEFAULT.BSSWING (BSSWING(1115mV)) ) "&  
  -- TDO  
  ")";
```

A tool which knows how to read REGISTER_ASSEMBLY and found only i1, i2 and i4 would
calculate that there are 3 x 6 bits or 18 bits of scan data.
(John Siebold example, recall SERDESH and SERDESO have a 6 bit tdr segment).


A tool could programmatically allow one to add to R_A or subtract from it.

It's possible for 1149.1-2012 package file to specify the POWER, CMUX and MUX. One bit senses power domain and enables control, the other bit controls the mux.


```
attribute REGISTER_MNEMONICS of std_1149_1_2012 : package is
`MUX      (On      (1) < chain segment is included >, " &
`         (Off      (0) < chain segment not included >), " &
`POWER    (On      (1) < Domain is functionally on> ), " &
`         (Off      (0) < Domain is functionally off>), " &
`CONTROL  (Override (1) < Test controls domain power to ON > ), " &
`         (Normal   (0) < Power domain in normal mode> )";
```

```
attribute REGISTER_FIELDS of std_1149_1_2012 : package is
`POWER[1] ( "&
"(DOMAIN [1] IS (0 ) DEFAULT(CONTROL(Normal)) "&
`         RESETVAL(Control(Normal)), "&
`         CAPTURES(POWER(-)) ) "&
`), " &
`CONTROL[1] ( "&
"(CMUX [1] IS (0 ) DEFAULT(MUX(Off) ), "&
`         RESETVAL(MUX(Off) ), "&
`         SELFMON ) "&
`), " &
`MUX[0] ( "&
"(MUX [0] IS (0 ) ) "&
`         );
```

at POR/RESET
domain is
in 'normal'
mode



at POR/RESET
mux control
is in 'off'
mode - segment
not included



- Note that one cell, the domain cell is responsible for sensing and overriding power independent of mux cell.
 - if power does not come on due to
 - 1) fault 2) board constraint

SAMPLE based scan-chain test done first. (some faults not seen until board ICs are in EXTEST though)

Test software can fail immediately at this point. Test engineer would not expand and turn on domain.

- diagnostic software could
 - run smaller interconnect test with smaller number of domains 'on'.

Use of POWER & MUX in R_A

Consider if SERDESH is in a separate POWER Domain

attribute REGISTER_ASSEMBLY of chip_2011 : entity is

```
"INIT_DATA ( "&
  -- TDI
  "(USING SerdesO),( i1 IS init_data DEFAULT.ALLBITS (CHPMFG(Test)) ), "&
  "(USING SerdesO),( i2 IS init_data DEFAULT.ALLBITS (CHPMFG(Test)) ), "&
  "(USING STD_1149_1_2012), "&
  "( P1 IS POWER CHRESET ), "& "( c1 IS CONTROL CHRESET ), "&
  "(USING SerdesH),( i3 IS init_data DEFAULT.ALLBITS (CHPMFG(Test)) ), "&
  "(USING SerdesO),( i4 IS init_data DEFAULT.BSTERM (BSTERM(CPflt))
  DEFAULT.BSCM (BSCM(DC_CPL)) DEFAULT.BSSWING (BSSWING(1115mV)) ) "&
  -- TDO
  "( mux1 IS MUX ), "&
  ");
```



this portion is on/off depending on domain
and mux register_fields of the Powermux (see
package file descriptions on prior page

Basic Rules/Operation

- 1) For power segments which can be observed or control/observed, at least one POWER TDR bit and Control (CMUX) cell is required per segment.
- 2) The segment is defined between the CONTROL and the MUX
- 3) There must always be a pair of CONTROL and MUX
- 4) CONTROL (CMUX) cell bits are always reset to the short, collapsed segment
- 5) MUX is a zero bit field and is used to indicate where the mux in the TDR exists
- 6) there is no overlap/heirarchy

TDRs can be built using R_A and R_F, however boundary registers do not follow R_F format.

BOUNDARY_REGISTER_SEGMENT enables R_A to be used with the bscan register

Here we have 4 B-R segments. Control cells for all I/O have to be within the segment number is local to the segment

attribute BOUNDARY_REGISTER_SEGMENT of east : entity is

```
-- num cell port function safe [ccell disval rslt]
"10 (BC_1, *, controlr, X)," &
"9 (BC_1, D(0), input, X, PULL0)," &
"8 (BC_1, D(1), input, X, PULL0)," &
"7 (BC_1, Q(1), output3, X, 10, 1, PULL0)," &
"6 (BC_1, Q(2), output3, X, 10, 1, PULL0)," &
"5 (BC_1, Q(3), output3, X, 10, 1, PULL0)," &
"4 (BC_1, Q(4), output3, X, 10, 1, PULL0)," &
"3 (BC_1, Q(5), output3, X, 10, 1, PULL0)," &
"2 (BC_1, Q(6), output3, X, 10, 1, PULL0)," &
"1 (BC_1, Q(7), output3, X, 10, 1, PULL0)," &
"0 (BC_1, Q(8), output3, X, 10, 1, PULL0)";
```

attribute BOUNDARY_REGISTER_SEGMENT of west : entity is

```
-- num cell port function safe [ccell disval rslt]
"10 (BC_1, *, controlr, X)," &
"9 (BC_1, D(2), input, PULL0)," &
"8 (BC_1, D(3), input, PULL0)," &
"7 (BC_1, Q(9), output3, X, 10, 1, PULL0)," &
"6 (BC_1, Q(10), output3, X, 10, 1, PULL0)," &
"5 (BC_1, Q(11), output3, X, 10, 1, PULL0)," &
"4 (BC_1, Q(12), output3, X, 10, 1, PULL0)," &
"3 (BC_1, Q(13), output3, X, 10, 1, PULL0)," &
"2 (BC_1, Q(14), output3, X, 10, 1, PULL0)," &
"1 (BC_1, Q(15), output3, X, 10, 1, PULL0)," &
"0 (BC_1, Q(16), output3, X, 10, 1, PULL0)";
```

attribute BOUNDARY_REGISTER_SEGMENT of south : entity is

```
-- num cell port function safe [ccell disval rslt]
"10 (BC_1, *, controlr, X)," &
"9 (BC_1, D(4), input, PULL0)," &
"8 (BC_1, D(5), input, PULL0)," &
"7 (BC_1, Q(17), output3, X, 10, 1, PULL0)," &
"6 (BC_1, Q(18), output3, X, 10, 1, PULL0)," &
"5 (BC_1, Q(19), output3, X, 10, 1, PULL0)," &
"4 (BC_1, Q(20), output3, X, 10, 1, PULL0)," &
"3 (BC_1, Q(21), output3, X, 10, 1, PULL0)," &
"2 (BC_1, Q(22), output3, X, 10, 1, PULL0)," &
"1 (BC_1, Q(23), output3, X, 10, 1, PULL0)," &
"0 (BC_1, Q(24), output3, X, 10, 1, PULL0)";
```

attribute BOUNDARY_REGISTER_SEGMENT of north : entity is

```
-- num cell port function safe [ccell disval rslt]
"10 (BC_1, *, controlr, X)," &
"9 (BC_1, D(6), input, PULL0)," &
"8 (BC_1, D(7), input, PULL0)," &
"7 (BC_1, Q(25), output3, X, 10, 1, PULL0)," &
"6 (BC_1, Q(26), output3, X, 10, 1, PULL0)," &
"5 (BC_1, Q(27), output3, X, 10, 1, PULL0)," &
"4 (BC_1, Q(28), output3, X, 10, 1, PULL0)," &
"3 (BC_1, Q(29), output3, X, 10, 1, PULL0)," &
"2 (BC_1, Q(30), output3, X, 10, 1, PULL0)," &
"1 (BC_1, Q(31), output3, X, 10, 1, PULL0)," &
"0 (BC_1, Q(32), output3, X, 10, 1, PULL0)";
```


Need to support register_assembly already for
INIT_DATA and user TDRs - could be handy for BSCAN register
- when init_data is present both registers need power mux

attribute REGISTER_ASSEMBLY of chip_2012 : entity is

```
"BOUNDARY ( "&  
  -- TDI  
  "( p1 IS POWER ), ( c1 IS CONTROL ), "&  
  "( i1 IS east ), "&  
  "( mux1 IS MUX ), "& -- zero bits  
  "( p2 IS POWER ), ( c2 IS CONTROL ),"&  
  "( i2 IS south ), "&  
  "( mux2 IS MUX ), "& -- zero bits. Note NESTING is not allowed.  
  "( M1 IS misc ), "& -  
  "( p3 IS POWER ), ( c3 IS CONTROL ),"&  
  "( i3 IS west ), "&  
  "( mux3 IS MUX ), "& -- contributes no bits to the scan chain  
  "( p4 IS POWER ), ( c4 IS CONTROL ),"&  
  "( i4 IS north )" &  
  "( i4 IS MUX ), "& -- no bits in scan chain – just the return path  
  "( M2 IS misc ), "& -- additional pins/cells in TAP power domain  
  -- TDO  
  ")";
```

Power Must be on

I'm worried that the b-s register will become corrupt with these mux control bits
- recall the original figure. be more worried of the effects of
a single b-s register with segmented power.



recall also that - a '0' shifted into an internal cell position in the
boundary register can also corrupt the b-s register contents.

```
" 197 ( BC_1 , * , internal , 1 ) , " &
```

```
" 198 ( BC_1 , * , internal , 1 ) , " &
```

it's been manageable for 20+ years now to get these bits set right

PDL - what a tool should do

```
# turn on P1 power domain
iWrite p1.domain Override
iWrite p2.domain OverrIde
iApply
# check it is on
iRead p1.domain On
iRead p2.domain On
iApply -loopuntil pass
# turn on mux
iWrite p1.cmux On
iApply
```

```
attribute REGISTER_MNEMONICS of std_1149_1_2012 : package is
"MUX (On (1) < chain segment is included >, " &
" Off (0) < chain segment not included >), " &
"POWER (On (1) < Domain is functionally on> ), " &
" Off (0) < Domain is functionally off>), " &
"CONTROL (Override (1) < Test controls domain power to ON > ), " &
" Normal (0) < Power domain in normal mode> )";
```

```
attribute REGISTER_FIELDS of std_1149_1_2012 : package is
"POWER[1] ( "&
"(DOMAIN [1] IS (0) DEFAULT(CONTROL(Normal)) " &
" RESETVAL(Control(Normal)), "&
" CAPTURES(POWER(-)) )" &
")," &
"CONTROL[1] ( "&
"(CMUX [1] IS (0) DEFAULT(MUX(Off) ), "&
" RESETVAL(MUX(Off) ),"&
" SELFMON )" &
")," &
"MUX[0] ( "&
"(MUX [0] IS (0) )" &
" )";
```

```
attribute REGISTER_ASSEMBLY of chip_2012 : entity is
"BOUNDARY ( "&
-- TDI
"(p1 IS POWER ),(c1 IS CONTROL ),"&
"( i1 IS east ),"&
"( mux1 IS MUX ),"& -- zero bits
"(p2 IS POWER ),(c2 IS CONTROL ),"&
"( i2 IS south ),"&
"( mux2 IS MUX ),"& -- zero bits. Note NESTING is not allowed.
"( M1 IS misc ),"& -
"( p3 IS POWER ),(c3 IS CONTROL ),"&
"( i3 IS west ),"&
"( mux3 IS MUX ),"& -- contributes no bits to the scan chain
"( p4 IS POWER ),(c4 IS CONTROL ),"&
"( i4 IS north )" &
"( i4 IS MUX ),"& -- no bits in scan chain – just the return path
"( M2 IS misc ),"& -- additional pins/cells in TAP power domain
-- TDO
" )";
```

Custom sequences would have to be manually described in PDL

```
# turn on P1 power domain
iWrite p1.domain Override
iApply
#wait for a bit
iRunLoop 1000
#
iWrite p1.myspecialcell
iApply
#wait for a bit
iRunLoop 1000
# check it is on
iRead p1.domain On
iApply
# turn on mux
iWrite p1.cmux On
iApply
```

```
attribute REGISTER_MNEMONICS of std_1149_1_2012 : package is
"MUX (On (1) < chain segment is included >, " &
" Off (0) < chain segment not included >), " &
"POWER (On (1) < Domain is functionally on> ), " &
" Off (0) < Domain is functionally off>), " &
"CONTROL (Override (1) < Test controls domain power to ON > ), " &
" Normal (0) < Power domain in normal mode> )";
```

```
attribute REGISTER_FIELDS of std_1149_1_2012 : package is
"POWER[1] ( "&
"(DOMAIN [1] IS (0) DEFAULT(CONTROL(Normal)) " &
" RESETVAL(Control(Normal)), "&
" CAPTURES(POWER(-)) ) "&
")," &
"CONTROL[1] ( "&
"(CMUX [1] IS (0) DEFAULT(MUX(Off) ), "&
" RESETVAL(MUX(Off) ),"&
" SELFMON ) "&
")," &
"MUX[0] ( "&
"(MUX [0] IS (0) ) "&
" )";
```

```
attribute REGISTER_ASSEMBLY of chip_2012 : entity is
"BOUNDARY ( "&
-- TDI
"(p1 IS POWER ),(c1 IS CONTROL ),"&
"( i1 IS east ),"&
"( mux1 IS MUX ),"& -- zero bits
"(p2 IS POWER ),(c2 IS CONTROL ),"&
"( i2 IS south ),"&
"( mux2 IS MUX ),"& -- zero bits. Note NESTING is not allowed.
"( M1 IS misc ),"& -
"( p3 IS POWER ),(c3 IS CONTROL ),"&
"( i3 IS west ),"&
"( mux3 IS MUX ),"& -- contributes no bits to the scan chain
"( p4 IS POWER ),(c4 IS CONTROL ),"&
"( i4 IS north )"&
"( i4 IS MUX ),"& -- no bits in scan chain – just the return path
"( M2 IS misc ),"& -- additional pins/cells in TAP power domain
-- TDO
")";
```