

Example Implementation of the KR/CR tap weight restrictions

Athos Kasapi, Cadence

November 2019

802.3ck November Plenary Meeting, Hawaii USA

- This presentation is a continuation of the presentation kasapi_3ck_01_0119.pptx, and gives an example of how to implement the recommendation of slide 18.
- Some of the notation is changed here to correspond better with prior presentations and 802.3ck drafts.

In the equations/text describing how to calculate the DFE coefficients, including the amplitude and location of the DFE floating taps as per the adopted baseline walker_3ck_01d_0719.pdf (TBD for clause 162 and 163 as of draft 0.4), use b'_n instead of b_n in order to refer to provisional DFE coefficients ($n = 1 \cdots N_f$).

Here, for n in the range $N_{b+1} \cdots N_f$ only nine of the taps b'_n are nonzero and represent the floating taps.

After the calculation of the provisional DFE coefficients, b'_n , use the following procedure (or equivalent) to determine the final DFE coefficients:

- For coefficients $n = 1 \cdots N_{tail\ start} - 1$,

$$b_n = b'_n$$

- For coefficients $n = N_{tail\ start} \cdots N_f$, calculate

$$\|b_{float}\| = \sqrt{\sum_{n=N_{tail\ start}}^{N_f} (b'_n)^2}$$

For $n = N_{tail\ start} \cdots N_f$ the DFE coefficients b_n are given by

$$b_n = \min(\|b_{float}\|, \|b_{float}\|_{limit}) \frac{b'_n}{\|b_{float}\|}.$$

- Insert the following new parameters into table 93A-1 – COM params:
 - 1. $\|b_{float}\|_{limit}$
 - 2. $N_{tail\ start}$
- Specify the following parameters in table 163-10 – COM parameter values (KR) and the corresponding table 162-10 (CR) when it is assembled:
 - 1. $\|b_{float}\|_{limit} = 0.03$
 - 2. $N_{tail\ start} = 25$